










Backwashing the Koi Pond Filter (23 June 2023)


Stir up the dirt in the filter beads.

1		Switch off the pond pump at the wall socket.
2		Close the RED lever valve by turning it clockwise to the vertical position.
3		Select RINSE on the multiport valve .
4		Open the BLUE valve on the air-blower line by turning it anti-clockwise to the horizontal position.
5		a) Unplug the pond pump and plug the air-blower into the same socket. b) Switch on the air-blower for 2 to 3 minutes to stir up the dirt in the beads in the filter. c) Switch off the air-blower .
6		Close the BLUE air-blower lever valve by turning it clockwise back to the vertical position.


Backwash the stirred-up dirt in the filter.

7		Unplug the air-blower and plug in the pond pump . <i>Don't turn it on just yet.</i>
8		Select BACKWASH on the multiport valve .
9		a) Open the RED lever valve by turning it anti-clockwise back to its horizontal position. b) Switch on the pond pump (still pugged in) and run it until the wastewater is clear. c) Switch off the pond pump .

Rinse the filter.

10		a) Select RINSE on the multiport valve . b) Switch on the pond pump (still plugged in) and run it for 1 minute. c) Switch off the pond pump .
----	---	--

Back to normal.

11		a) Select FILTER on the multiport valve . b) Switch on the pond pump (still plugged in). c) Top-up the pond if necessary.
----	---	--